


FRONT LIGHT

INSERT BATTERIES


- 1.To insert batteries, remove the rear cover by turning counter-clockwise.(Fig.1)
- 2.Remove the battery case then insert 2 CR2032 batteries according to the polarity markings on the case.(Fig.2)






INSTALLATION

- 1. Pull the strap to fix into the bulge first.
- Install the light onto the handlebar and tighten it by strap.



TO SWITCH MODES

Press the lens on the front of the light.



SPECIFICATIONS

Size: $40 \times 28 \times 33 \text{ mm}$

Weight: 31 g

LED: Front light: 1 SMD White LED

Rear light: 1 SMD Red LED

Battery: CR2032 x 2

Bracket: Front light: Ø19-Ø32, with 2 rubber pads

Rear light: Ø19-Ø32, with 1 rubber pad



Manufactured by: Chance Good Ent. Co., Ltd. Quality System Registered to: ISO 9001 / 14001 Website: www.infini.com.tw



REAR LIGHT

INSERT BATTERIES


- 1.To insert batteries, remove the rear cover by turning counter-clockwise.(Fig.1)
- 2.Remove the battery case then insert 2 CR2032 batteries according to the polarity markings on the case. (Fig.2)






INSTALLATION

- 1. Pull the strap to fix into the bulge first.
- 2. Install the light onto the seat post or seat stay and tighten it by strap.



TO SWITCH MODES

Press the lens on the front of the light.





- 1. We recommend to remove batteries from the light during period of non-use to avoid the battery leakage.
- 2. For best performance, do not mix new and old batteries.
- 3.Carefully install batteries, insuring proper polarity.
- 4. For your own safety, please do not operate the controls of the product while riding.
- 5.Please keep the product out of children's reach.