



I-261W/WD

MOUNTING YOUR LIGHT

Install the light on the handlebar by using strap.




When the light and bracket is in horizontal condition, install the light on the bracket and twist it in the position of 90° and fasten it.



LIGHT REMOVAL

Twist the light in the direction of right and left into 90° and remove it from bracket.



TO SWITCH MODES

Press the button on the top of the light.


I-261W



I-261WD (Meets Danish Standard)




Optional : Helmet Bracket



Hook and loop fastener to mount onto a helmet.



Tighten up the velcro strap.




Clip the light on the helmet mount.


I-261R/RD

MOUNTING YOUR LIGHT

Install the light on the seat post, seat stay by using strap.




When the light and bracket is in horizontal condition, install the light on the bracket and twist it in the position of 90° and fasten it.



LIGHT REMOVAL

Twist the light in the direction of right and left into 90° and remove it from bracket.



TO SWITCH MODES

Press the button on the front of the light.

