



olley I-210P

MOUNTING YOUR LIGHT

1. Install the light on the handlebar by using ring .



2. When the light and bracket is in vertical condition, install the light on the bracket and twist it in the position of 90° and fasten it.



OPTIONAL

Helmet bracket HM02




Tighten up the velcro strap.



Clip the light on the helmet mount.

TO SWITCH MODES


Please press the button for 1.5 seconds to turn ON & OFF and click to switch modes.



olley I-210Ri




MOUNTING YOUR LIGHT

1. Mount the bracket on the seat post with the rubber ring by wrapping it around the post and latching it onto the hooked plastic bracket.
2. Install the light on the bracket by sliding it in from a horizontal position, then turning it 90° to lock it in place




TO SWITCH MODES

Please install the light on bracket then press the button for 1.5 seconds to turn ON & OFF and click to switch modes.




MOUNTING CLIP MOUNT


1. Install the light on the bracket.
2. Twist the light in the position of 90° and fasten it.




OPTIONAL-SADDLE RAIL BRACKET



1. Install the bracket under the saddle by using cable tie.
2. Tighten up the cable tie and cut the extra part of it by using scissors.



3. When the light and bracket is in horizontal condition, install the light on the bracket.



4. Twist the light in the position of 90° and fasten it.

BATTERY INDICATOR

3-level check function
shows actual remaining
power level
(approx.):

Power ON

Green : 100%~50%
Orange : 49%~25%
Red : 24%~0%

Power OFF

Double click to show the
remaining capacity.

I-210P



I-210Ri





When battery capacity is less than 10%,
the light automatically switches to low
constant or flashing mode.
This provides additional runtime.
The red indicator light can be seen, as
pictured. (Fig.1) Please charge the light
promptly until indicator light shuts off.

COMPONENTS

Light / Bracket / Pad / Ring / Velcro Strap / Clip Mount / USB Type-C To Type-A Male Cable

OPTIONAL



Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm

Ø 19~21.5mm